

CARING FOR YOUR

# Timber Chopping Board

**TRENDS**<sup>TM</sup>  
KITCHENS



Wood is a natural product and can be affected by water and heat, causing warping or splitting. Follow the guidelines below to obtain maximum service life from your solid timber chopping board.

## Care Instructions:

- ✓ **Store on edge** when not in use.
- ✓ **Clean reguarly** with a damp cloth.
- ✓ **Oil both sides reguarly** with vegetable oil.
  
- ✗ **Do not place in the dishwasher.**
- ✗ **Do not immerse in water.**
- ✗ **Do not expose to hot surfaces or direct sunlight.**

